

KRT SERIES



IMPORTANT SAFEGUARDS

When using electrical equipment, basic safety precautions should always be followed, including the following:

THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED. DISCONNECT POWER TO ALL CIRCUITS BEFORE WIRING FIXTURE. INSTALL IN ACCORDANCE WITH ALL NATIONAL, STATE, AND LOCAL CODES. DO NOT CONNECT TO AN UNGROUNDED SUPPLY. READ ALL FIXTURE MARKINGS AND LABELS TO ENSURE CORRECT INSTALLATION OF FIXTURE. SUPPLEMENTAL INSTRUCTIONS MAY BE LOCATED ON THE FIXTURE, IN ADDITION TO THIS INSTRUCTION SHEET, REGARDING ORIENTATION, OR MOUNTING RESTRICTIONS.

SAVE THESE INSTRUCTIONS

INSTALLATION INSTRUCTIONS

1. Read all fixture markings and labels to insure correct installation of the fixture. Additional information may be located on the fixture, separate from this instruction sheet, regarding orientation and mounting restrictions.
2. Always disconnect power to the circuit before wiring or servicing fixture.

Cord connected:

1. Fixtures supplied with a cord and 3-prong grounded plug suitable 120-volt only.
2. Mount fixtures to surfaces using (4) mounting location using appropriate fasteners for mounting surface (supplied by others).

Conversion for Conduit Connection:

1. Remove lens and reflector/wireway cover.
2. Disconnect supply cord connections from LED driver input leads.
3. Remove supply cord and strain relief bushing from housing.
4. Using hole reamer, open hole on end of housing used for cord bushing to accept 1/2 in. trade size fitting (7/8 in. diameter hole).
5. Attach conduit fitting for conduit.
6. Make electrical connections. Black fixture lead connects to the supply conductor, white fixture lead connects to the neutral supply conductor, and green grounding lead to the bare copper conductor.
7. Replace reflector/wireway cover and lens.

CUSTOMER SERVICE

For technical assistance, call 1-800-4KENALL (1-800-453-6255).

WARRANTY

For warranty information visit www.kenall.com/Resources/Certified-Performance-Warranties

