

STRATALUME CONNECTS™

MRIAUC SERIES

PRODUCT FEATURES:

- » Surface mount – solid front; 1.5' or 3' lengths
- » Non-ferrous construction
- » External mounting feet allow for easy installation
- » Antimicrobial finish and NSF2 listing for cleanability



PROJECT INFORMATION

Job Name _____

Fixture Type _____

Catalog Number _____

Approved by _____

SPECIFICATIONS

HOUSING: Non-ferrous extruded marine-grade aluminum. Nominal thickness: .060". Antimicrobial finish standard on housing and driver cover.

LENS: UV-stabilized, high-impact resistant, extruded frost 100% DR acrylic. Smooth exterior, linear prism interior. Snap-in tool-less entry design.

END CAPS/COVERS: UV-stabilized, high-impact resistant, injection-molded white or black opaque polycarbonate. Black end caps/covers provided when silver finish (SL) is ordered. Light leak-preventing interlocking design.

ELECTRICAL: Serviceable high-brightness LED array. See Ordering Information for available color temperature options. Five-step MacAdam variation allowance. 80 CRI minimum. Luminaire input 24VDC from remote-located 120-277VAC, high-power-factor power supply with EMI filter. Dimming line EMI filter required if utilizing dimming function. Dimming capability controlled through compatible 0-10V dimmer (supplied by others). MRI room EMI filter required for both 24V and dimming line (supplied by others). See below for ordering information.

HARDWARE: Non-ferrous hardware and internal bracketing.

GASKET: Closed-cell extruded EPDM gasket seals lens to end caps.

INSTALLATION: All power and signal wiring must be completely shielded in grounded conduit. External mounting feet allow installation without accessing internal compartments. Four-point mounting required. 3/8" conduit fitting supplied.

PHOTOMETRICS: Photometry tested to the IESNA LM-79-08 standard by an ILAC/ISO17025 accredited laboratory. For photometric information, go to www.kenall.com.

WARRANTY: Limited five (5) year LED warranty.

LISTINGS: Luminaire is certified to UL1598 and UL8750 standards by Intertek Testing Services for Damp Location. NSF2 Splash/Non-Food Zone.



ORDERING INFORMATION (Ex: MRIAUC-I-MW-14L40K-24VDC)

Model	Installation Type	Finish	Lamp Type	Voltage	Options
MRIAUC	I			24VDC	
	Installation Type		Lamp Type	Voltage	
	I Individual Mount		18.5" Length	24VDC 24 Volts DC	
	Finish		14L30K 14 Watt 3000K LED, 80 CRI	Options	
	MW Matte White		14L35K 14 Watt 3500K LED, 80 CRI	SW Rocker Switch	
	MB Matte Black		14L40K 14 Watt 4000K LED, 80 CRI		
	SL Silver		35" Length		
	CCW Custom Color Housing with White end caps		27L30K 27 Watt 3000K LED, 80 CRI		
	CCB Custom Color Housing with Black end caps		27L35K 27 Watt 3500K LED, 80 CRI		
			27L40K 27 Watt 4000K LED, 80 CRI		

ACCESSORIES ORDERED SEPERATELY

MRIPSF	Remote Power Supply with EMI Filter (click here for specifications)
MRIFD-1A	Dimming Filter (one per dimming circuit, click here for specifications)

MRI LUMINAIRE CONNECTION PER POWER SUPPLY

Luminaire Number	Lamp Power	Amps/ Luminaire	Max Luminaires per MRIPSF-480 Power Supply	Max Luminaires per MRIPSF-240 Power Supply	Max Luminaires per MRIPSF-120 Power Supply
MRIAUC	14L	0.76	26	13	6
MRIAUC	27L	1.52	13	6	3



www.kenall.com | P: 800-4-Kenall | F: 262-891-9700 | 10200 55th Street Kenosha, Wisconsin 53144, USA
 This product can comply with the latest domestic preference legislation, such as the Buy American Act (BAA), Trade Agreement Act (TAA), Build America, Buy America Act (BABA), and others. It may be covered by patents found at www.kenall.com/patents. Content of specification sheets is subject to change; please consult www.kenall.com for current product details. ©2024 Kenall Mfg. Co.

A brand of **legrand**

STRATALUME CONNECTS™


MRIAUC SERIES

PERFORMANCE

Nominal Length	Lamp Type	Initial Delivered Lumens		Input Power (W)	Drive Current (mA)	Estd. L70 LED Life (Hrs)
		@ 25°C	Efficacy (lm/W)			
18.5"	14L30K	1,072	70	15	117	80,000
	14L35K	1,141	74	15	117	80,000
	14L40K	1,141	74	15	117	80,000
35"	27L30K	2,147	71	30	117	80,000
	27L35K	2,286	75	30	117	80,000
	27L40K	2,286	75	30	117	80,000


Product tested with MW Finish Type. Information subject to change without notice. Visit www.kenall.com for IES files and additional information.

Model: MR1AUC-I-MW-14L35K-24VDC




Max Candela = 510 Located At Horizontal Angle = 60, Vertical Angle = 5
 — 1 - Vertical Plane Through Horizontal Angles (60-240) (Through Max. Cd.)
 — 2 - Horizontal Cone Through Vertical Angle (5) (Through Max. Cd.)

Model: MR1AUC-I-MW-27L40K-24VDC




Max Candela = 1017 Located At Horizontal Angle = 15, Vertical Angle = 5
 — 1 - Vertical Plane Through Horizontal Angles (15-195) (Through Max. Cd.)
 — 2 - Horizontal Cone Through Vertical Angle (5) (Through Max. Cd.)

DIMENSIONAL DATA



LENGTH DIMENSION – MR1AUC SERIES

LAMP	in (mm)
14W LED	18.50 (470)
27W LED	35.00 (889)



MRIAUC SERIES

IMPORTANT SAFEGUARDS

When using electrical equipment, basic safety precautions should always be followed, including the following:

THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED. DISCONNECT POWER TO ALL CIRCUITS BEFORE WIRING FIXTURE. INSTALL IN ACCORDANCE WITH ALL NATIONAL, STATE, AND LOCAL CODES. DO NOT CONNECT TO AN UNGROUNDED SUPPLY. READ ALL FIXTURE MARKINGS AND LABELS TO ENSURE CORRECT INSTALLATION OF FIXTURE. SUPPLEMENTAL INSTRUCTIONS MAY BE LOCATED ON THE FIXTURE, IN ADDITION TO THIS INSTRUCTION SHEET, REGARDING ORIENTATION, OR MOUNTING RESTRICTIONS.

SAVE THESE INSTRUCTIONS

INSTALLATION INSTRUCTIONS

This instruction sheet applies for the Stratalume™ Connects™ MRI undercabinet product. A separate instruction sheet is provided in the MRIPSF external power supply system. Both sheets are intended to provide comprehensive instructions on fixture installation and wiring. This product contains sensitive electronics. Take care to avoid damage by improper handling or static electricity discharge (ESD). Either type of damage could render the system inoperable or cause latent failure.

The hardware bag contains the following non-ferrous hardware:

- (A) - One 3/8" connector clamp
- (B) - One 3/8" conduit fitting
- (C) - One connector nut
- (D) - Two 8-32 × 3/4" screws
- (E) - One 8-32 × 3/16" screws
- (F) - Four #8 × 1/2" mounting screws




Figure 1 Rear View





Figure 2 Included Hardware



Luminaire Mounting Procedure


Before beginning, make sure all components have been unpacked from the shipping carton.

1. Determine where fixture(s) will be mounted.
2. When fixture is positioned correctly, secure fixture by the mounting holes (see Figure 1) with four #8 screws (F).



Electrical Connection

3. Mount and wire the MRIPSF external power supply system per the procedures provided in the supplementary instruction sheet. Run conduit and DC wiring to an MRI room EMI filter. Make sure wiring is completely enclosed in grounded aluminum conduit. Any gaps, regardless of size, must be closed or wrapped in copper foil tape.
4. If a 0-10V dimming circuit is to be connected, install at this time. The 0-10V dimmer must be installed outside the shielded MRI environment with the Kenall MRIFD-1A dimming line filter (or equivalent) installed in accordance with the supplied installation instructions. Kenall recommends the Lutron Diva (DVSTV) and Lutron Nova T (NTSTV-DV) series to ensure the full range of dimming can be achieved. Contact Kenall for suitability of using an alternate sink-type 0-10V dimmer.




NOTE: 24VDC and Dimming Wires to be run through same conduit.



WARNING: All DC power and dimming signal wiring must be run through separate EMI filters.

5. After the luminaires are mounted and secured, access the internal junction box to gain access to supply connections. Each wire is labeled and color coded for easy identification.
6. Run DC supply wiring, equal in size and temperature rating to the filter input wiring, between the filter output cables and the first luminaire within the shielded room. Follow recommended wiring layout described within Single-Supply System Schematic. All wiring must be within completely-enclosed, grounded conduit suitable for an MRI environment. Any gaps, regardless of size, must be closed or wrapped in copper foil tape. Special attention should be paid to the wiring entry point into the shielded space. Class 1 wiring methods are required.
7. Run the dimming signal wiring, equal in specification to the filter input wiring, between the filter output cables and the first luminaire within the shielded room. Maintain polarity between input and output sides of the filter and follow wiring recommendation in Multi-Fixture Wiring Schematic. All wiring must be within completely enclosed, grounded conduit suitable for an MRI environment. Any gaps, regardless of size, must be closed or wrapped in copper foil tape. Special attention should be paid to the wiring entry point into the shielded space. Cap gray (or pink) and violet leads at luminaire(s) if dimming function is not implemented.
8. Make DC supply and (optional) dimmer control connections within each luminaire.



9. Reinstall all provided bracketry and internal enclosures provided with the luminaire. These parts are critical to the overall EMI shielding of the system.
10. Connect power to external power supply and test for proper operation of lighting system. Make sure all LEDs are lit and dimming operation works as intended (if connected).
11. Test operation of lighting during MRI machine idle mode and during scanning operations.
- 12. Fill out the Installation Registration Form and fax to Kenall at (262) 891-9701.**

CUSTOMER SERVICE

For technical assistance, call 1-800-4KENALL (1-800-453-6255).

WARRANTY



www.kenall.com | P: 800-4-Kenall | F: 262-891-9700 | 10200 55th Street Kenosha, Wisconsin 53144, USA
 This product can comply with the latest domestic preference legislation, such as the Buy American Act (BAA), Trade Agreement Act (TAA), Build America, Buy America Act (BABA), and others. It may be covered by patents found at www.kenall.com/patents. Content of specification sheets is subject to change; please consult www.kenall.com for current product details. ©2024 Kenall Mfg. Co.

A brand of Legrand

CUSTOMER ACKNOWLEDGEMENT

Customer acknowledges that these Installation Instructions are part of the product specification, and that the attached Installation Registration Form will be provided to the installer to sign and return to Kenall after installation is complete. This signed release is required by Kenall before order will be released into production.

Signature: _____

Date: _____

Print Name: _____

Company Name: _____

IMPORTANT SAFEGUARDS

To prevent MRI machine interference, all DC power and dimming signal wiring must be completely shielded within grounded aluminum conduit and a suitable MRI room EMI filter must be installed on each line.

When using electrical equipment, basic safety precautions should always be followed, including the following:
THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.

SAVE THESE INSTRUCTIONS

-
- Disconnect power to all circuits before wiring system.
 - Install in accordance with all national, state, and local codes.
 - Do not connect to an ungrounded supply.
 - Wiring connections must be made internal to the enclosure.
 - Failure to install unit on a mechanically-sound surface may result in personal injury, physical damage, or potential fire hazard.
 - Use installation procedures appropriate for an environment involving MRI and sensitive electronic equipment.
 - Read all markings and labels to ensure correct installation of the power supply. Supplemental instructions may be located on the enclosure, in addition to this instruction sheet, regarding orientation, or mounting restrictions.
 - Read instructions provided with the MedMaster™ MRIPSF remote power supply and DC filter system for proper installation and electrical connection to the lighting system.



CUSTOMER ACKNOWLEDGEMENT

MRI INSTALLATION REGISTRATION FORM

Customer acknowledges that the attached Installation Registration Form will be provided to the installer to sign and return to Kenall after installation is complete. For warranty purposes, please fill out this form and return to Kenall by fax at (262) 891-9701.

I certify that the lighting installation for the listed MRI suite location is completed per the provided installation instructions and to the best of my abilities.

Please check off items to denote status:

- Installation instruction sheets for MRIPSF-480 remote power supply and DC filter system and individual luminaire(s) read and followed.
- MRIPSF-480 power supply and EMI filters are located outside the shielded enclosure.
- All DC supply wiring is completely enclosed within grounded aluminum conduit. Installation has no ungrounded/unshielded portions of conduit or openings of any size or shape.
- All dimming signal wiring is completely enclosed within grounded aluminum conduit. Installation has no ungrounded/unshielded portions of conduit or openings of any size or shape. Check here if dimming is not applicable:
- If supplied by others, MRI Room EMI filters for the 24VDC supply and dimming signal are of the type intended for MRI suites and are sized to the electrical load.
- DC supply power and dimming signal are NOT running through the same EMI filter. Check here if dimming is not applicable:
- Lighting system fully tested (including dimming operation, if applicable) while MRI machine is in idle and scan operation mode.

If any of these steps cannot be completed or you need technical assistance, please contact Kenall Technical Support at 1-800-4KENALL (1-800-453-6255).

Electrical Contractor

Installation Site

Name: _____

Name: _____

City/State: _____

City/State: _____

Phone: _____

FAX FORM TO (262) 891-9701

Installation Date: _____

(Do not write below line)

Kenall Received By: _____

Received Date: _____



www.kenall.com | P: 800-4-Kenall | F: 262-891-9700 | 10200 55th Street Kenosha, Wisconsin 53144, USA
This product can comply with the latest domestic preference legislation, such as the Buy American Act (BAA), Trade Agreement Act (TAA), Build America, Buy America Act (BABA), and others. It may be covered by patents found at www.kenall.com/patents. Content of specification sheets is subject to change; please consult www.kenall.com for current product details. ©2024 Kenall Mfg. Co.

A brand of Legrand

MRIAUC-042122