


Existing Flat Part	S	I
---	No	No
Existing Form Part	S	I
---	No	No

REVISIONS				
REV.	ECN NO.	DESCRIPTION	BY	DATE



#8 HARDWARE (INCLUDED)

4.55

CEILING SUPPORT (4) PRE-ASSEMBLED FACTORY PRESET FOR 5/8" CEILING THICKNESS

1/4-20 HARDWARE (INCLUDED)

DETAIL B SCALE 1 : 2.5

#10 HARDWARE (INCLUDED)

DETAIL A SCALE 1 : 2.5

ASSEMBLE END FRAME TABS OUTSIDE OF SIDE FRAMES ALIGN WITH HOLES

INSTALL FRAME ASSEMBLY (SEE NOTE, SHEET 2)

This document contains information that is privileged, confidential or otherwise protected from use and disclosure. You are hereby notified that any review, disclosure, copying, dissemination or taking of any action in reliance on its contents or other use is strictly prohibited. This document and its contents are confidential proprietary information of Kenall Manufacturing Company.

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE:		
FRACTIONS	DECIMALS	ANGLES
--	.XXX ± 0.15	± 1/2°
MATERIAL:	NA	
FINISH:	NA	
CAD GENERATED DRAWING, DO NOT MANUALLY UPDATE		DATE
DRAWN AND APPROVED BY	ZSK	4/29/2021
SCALE: -- DO NOT SCALE DRAWING		REV. 0

Kenall
1020 Lakeside Drive Gurnee Illinois 60031

INSTR; INSTALL FRM ASSY
CSERO/I

F-8217

SHT: 1 OF: 2

Existing Flat Part	S	I
---	No	No
Existing Form Part	S	I
---	No	No





NOTE: PRE-ASSEMBLED INSTALL FRAME WILL NOT FIT THROUGH CEILING CUTOUT FROM ROOM SIDE.

IF PLENUM ACCESS IS AVAILABLE, PRE-ASSEMBLE INSTALL FRAME, AND LOWER INTO CEILING CUTOUT.
IF INSTALL FRAME IS TO BE INSTALLED FROM ROOM SIDE, LIFT END FRAMES, SIDE FRAMES AND CENTER BRACE INTO CEILING CUTOUT, AND ASSEMBLE TOGETHER WITHIN PLENUM.


ADJUST CEILING SUPPORTS (4) UNTIL BOTTOM OF INSTALL FRAME IS FLUSH WITH ROOM SIDE OF CEILING CUTOUT.
CEILING THICKNESS RANGE : 1/2" TO 3/4".

SECURE FRAME TO SUPERSTRUCTURE USING METHOD APPROPRIATE FOR THE INSTALLATION (E.G., THREADED ROD, HANGER WIRE ETC.) SUPPORTING METHOD AND HARDWARE BY OTHERS

RECOMMENDED CEILING CUTOUT



DETAIL C
SCALE 2 : 5



- RAISE FIXTURE INTO INSTALL FRAME
- TURN SWING ARM BOLTS (4) CLOCKWISE TO DEPLOY SWING ARMS AND ENGAGE INSTALL FRAME
- CONTINUE TURNING SWING ARM BOLTS CLOCKWISE UNTIL FIXTURE IS FIRMLY AND EVENLY SEATED AGAINST CEILING

This document contains information that is privileged, confidential or otherwise protected from use and disclosure. You are hereby notified that any review, disclosure, copying, dissemination or taking of any action in reliance on its contents or other use is strictly prohibited. This document and its contents are confidential proprietary information of Kenall Manufacturing Company.

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE:		
FRACTIONS	DECIMALS	ANGLES
--	.XXX±.015	±1/2°
MATERIAL: NA		
FINISH: NA		
CAD GENERATED DRAWING, DO NOT MANUALLY UPDATE		
DRAWN AND APPROVED BY	DATE	
ZSK	4/29/2021	
SCALE: -- DO NOT SCALE DRAWING		

Kenall
1020 Lakeside Drive Gurnee Illinois 60031

INSTR; INSTALL FRM ASSY
CSERO/I

F-8217

SIZE: B DWG. CAD FILE No: B
SHT: 2 OF: 2 REV: 0